





Instruction of pairing Aluprof remotes



ROLLER SHUTTERS





General Recommendations:

The installation and configuration of the blind should be carried out only by a trained installation team. It is essential to comply with all relevant health and safety regulations, particularly those concerning work at height and with electrical equipment.

Programming the First Remote Control

- 1. Enter the motor's programming mode by pressing the button on the motor's antenna.
- 2. Press the P2 button on the remote control twice.
- 3. Press the Up button.
- 4. The motor will emit a sound signal.
- 5. The remote control is now paired and ready for use.

Adding an Additional Remote Control

- 1. On a previously programmed remote, press the P2 button twice.
- 2. On the new remote, press the P2 button once.
- 3. After hearing a sound from the motor, press the Up button on the new remote.
- 4. The new remote has been successfully paired with the motor.

Removing All Remote Controls

- 1. Press the P2 button on a programmed remote control.
- 2. Press the Stop button.
- 3. Press the P2 button again.
- 4. Press the Stop button once more.
- 5. All remotes have now been disconnected from the motor.





